



Scan Setting

Delete Email Address

1. Tap []
2. Tap [Utility]
3. Tap [Utility]
4. Tap [Store Address]
5. Tap [Address book]
6. Choose the Email, then touch [Delete]
7. Tap []

掃描設定

刪除電郵地址

1. 按 []
2. 按 [實用功能]
3. 按 [實用功能]
4. 按 [目的地記錄]
5. 按 [預約位址]
6. 選擇需要刪除的電郵，再按 [刪除]
7. 按 []

