





# Setting

## Disable 2 color function (in Copy)

1. Tap [  ]
2. Tap [Utility]
3. Tap [Administrator]  
Enter password
4. Tap [System Settings]
5. Tap [Custom Function Pattern Selection]
6. Choose [Standard] at [Copy/Print Screen Pattern]  
**\*\*Some functions will be hidden**
7. Tap [  ] to save setting

# 設定

## 禁用雙色功能 (僅限複印)

1. 按 [  ]
2. 按 [實用功能]
3. 按 [管理者]  
輸入密碼
4. 按 [系統設定]
5. 按 [自訂圖樣功能]
6. 於 [複印/打印畫面圖式]，選擇 [標準]  
**\*\*部份功能會被隱藏**
7. 按 [  ] 儲存設定

