

Print Function

列印功能

Print Envelope or Custom Size Paper (Windows OS)




列印信封或自定尺寸紙張 (Windows OS)

Printer Driver Setting

1. Open the document file
2. Click [Print] to select printer driver.
3. Click [Printer Properties] / [Properties]
4. Click [Basic]
5. In [Paper size] select Envelope size or [Custom Size] (Input custom size value [Width] & [Length])
6. When printing envelope, select [Envelope] in Paper Type.
7. Click [OK]
8. Execute printing

Machine Setting

9. Load paper or envelope face down on bypass tray and touch [Complete] to print



列印驅動程式設定

1. 開啟文件
2. 按 [列印]，選擇印表機
3. 按 [印表機內容] / [內容]
4. 按 [基本的]
5. 於 [紙張尺寸] 選信封尺寸 或 [自定尺寸](輸入 [寬度] 和 [長度])
6. 列印信封時，於紙張種類選 [信封]
7. 按 [確定]
8. 執行列印

裝置設定

9. 把紙張/信封放在手動送紙上(印面向下)，並按 [完成] 進行打印