# Fax Setting

1. Tap [🏠]

2. Tap [Utility]

3. Tap [Administrator]
   Enter Administrator password

4. Tap [Fax Settings]

5. Tap [Report Settings]

6. Choose the setting on [TX Result Report]
   - [Always]: The report is printed every time a fax has been sent.
   - [If TX Fails]: The report is printed if a fax transmission has failed.
   - [OFF]: The report is not printed

7. Tap [OK]

傳真設定

1. 按 [🏠]

2. 按 [實用功能]

3. 按 [管理者]
   輸入管理者密碼

4. 按 [傳真設定]

5. 按 [報表設定]

6. 在 [發送報告] 中選擇
   - [經常]：在每次傳送傳真時列印報告
   - [僅限錯誤]：在傳真失敗時列印報告
   - [關閉]：不列印報告

7. 按[OK]