




Mobile Print

Add Printer (IOS)


* Mobile device and printer must under a same network

1. Tap [] OR Tap [] and Choose [Select and Add Printer]



OR
或

2. In [Select Printer], Tap []




Mobile Print

新增印表機 (IOS)

* Mobile 裝置必須和打印機位於同一網絡中

1. 按 [] 或 選取 [] [選擇並新增印表機]




2. 在 [選擇印表機], 按 []


Mobile Print

Add Printer (IOS)

3. Tap [Auto] to search devices or Tap [Manual] to direct input device's IP address.



4. In [Auto], Tap desired device and Tap [Add]




Mobile Print

新增印表機 (IOS)

3. 按 [自動] 搜尋印表機，或按 [手動] 直接輸入印表機的 IP 地址


4. 在 [自動]，選擇所需的印表機，再按 [新增]



Mobile Print

Add Printer (IOS)


5. Tap [OK]



Mobile Print




新增印表機 (IOS)

5. 按 [OK]



6. In [Manual], Type the IP address of printer directly and Tap [Search]

7. Tap [OK]



6. 在 [手動]，直接輸入 IP 位址，然後按 [搜尋]

7. 按 [OK]